



1160 South Street
Suffield, CT 06078



WCS™ Pro Scissors Mole Trap

Instructions

1. To identify active mole tunnels, gently flatten out a portion of the tunnel. Wait 24 hours. Tunnels that resurface are most likely active tunnels. Set traps in these active tunnel locations.
2. Remove and expose the active tunnel. It is recommended the lawn be “peeled” back to preserve for use after mole has been caught. Remove just enough dirt to fit the trap. Mound up the soil where the lawn has been peeled back.
3. Use the setting tools provided and place each of them on the spring of the trap.
4. Ensure the arm bar is placed over the top of the trap and through one of the setting tools.
5. Squeeze the setting tools together. This will require some strength.
6. When setting tools are fully compressed, place end of arm bar on the pan. Temporarily set the safety hook around the top of the other trap leg. Release safety hook only when trap is properly positioned.
7. Place the set trap in the mound that was recently created aligning it with the straight section of the tunnel. Legs should be deep enough to allow front tip of pan to touch the mound created. Loosely replace the soil back into the hole so no light penetrates the tunnel. Release the safety hook only when the trap is properly positioned.
8. After the trap has fired, remove mole if desired.