



Suggestions for Best results using PRO-CONE Squirrel

- Determine squirrel activity by locating entry and exit point(s) on structure.
- Install cone(s) over hole(s). *Please note* - Squirrel cone(s) can be installed at any angle.
- It's imperative to "squirrel proof" all *inactive* areas of structure before installing cone(s) to prevent squirrels from relocating to other areas such as: Attic vents, louvers, corners of dormers and soffit areas etc... We suggest using metal flashing and/or ¼ inch wire mesh (hardware cloth) to help prevent possible re-infestation.
- We recommend leaving squirrel cone(s) in place for a minimum of three (3) to five (5) days to insure that squirrels are out.
- When you are certain that squirrels are gone, remove squirrel cone(s) and seal hole(s) with metal flashing and trim trees around structure to help prevent further re-infestation.

Caution!

DO NOT remove squirrels during their birthing cycles! This will result in offspring becoming trapped inside!!!

Failure to follow these directions, will force female squirrel to chew her way back in to reach her young!!!

Please consult your State Wildlife Agency for information regarding squirrel birthing cycles in your area!!!