



P.O. Box 538
East Granby, CT 06026
Ph: (860) 844-0101
www.wildlifecontrolsupplies.com

Weep Hole Cover Instructions

Tools:

- ◆ 3/8 inch Masonry Bit
- ◆ Standard 3/8 inch Drill
- ◆ Shop Vac or Vacuum with hose
- ◆ Flat head Screw Driver
- ◆ Metal Snips or Hacksaw

Step 1-Prep:

For best results clean the weep hole of all debris. Measure the brick depth, set drill bit 1/2 inch deeper. Standard weep holes are 3/8inch in width but will vary. A smaller or larger masonry bit may be required.

Step 2-Remove Debris

Clear out debris by moving the drill up and down in the weep hole until the bit penetrates to the desired depth and height. For aesthetics, make sure the height of the weep holes is consistent down the wall.

Step 3-Clean

Use the Shop Vac or vacuum with an attached suction hose and vacuum out debris. You may need to use a flathead screw driver to remove large pieces.

Step 4-Size:

Measure the height of the weep hole and use the metal snips or hacksaw to cut to size.

Step 5-Final Installation:

Squeeze the flanges together and push in place. The cover can be flush in the weep hole or recessed.

Maintenance: Remove and wash if weep hole covers get clogged with debris.