## BERKSHIRE DISPOSABLE **STAKES**

## **Directions**

1. No special driver is needed. You can use any 3/8" stake that has a pencil point (figure 1). The driver should be approx 6" longer than the depth that you will be driving the disposable stake. NOTE: The drivers for the Heavy Duty and Soft Ground Disposable Stakes have to be more pointed than the one for the Standard Disposable Stakes. If the driver for the Heavy Duty Disposable Stake and Soft Ground anchor isn't pointed enough, as in figure 1, it will bend the stake point thus allowing the driver to slip off the stake.

Figure 1 Driver Point for Driver Point for Incorrect Heavy & Soft Ground Disp. Standard Disp. Stake Stakes

2. How deep you drive the Berkshire Disposable Stake depends on your soil type but usually 15" is a good depth for the Standard and Heavy disposable stake and the Softground should be driven to approximately of 30" in soft ground. (figure 2)



Pointed Stake

Figure 2

3. When you have driven the disposable stake to the depth that you want, simply remove the driver (rod) then pull on the cable to set the disposable stake. (figure 3)

you use an inline swivel to attach the cable to the trap chain.



4. When using the Berkshire Disposable stake we recommend that Lock In Place

Figure 3