

Jackite Flying Eagle Kite

Windsock Flying

Attach swivel through hole in beak. Attach line to swivel. Winds tend to be variable and gusty, posing many problems for the kite flyer. Your **Jackite** will fly wonderfully from a pole even under these conditions. Using 8 feet of line, simply attach your **Jackite** to a 20 foot flexible pole (collapsible, available from **Jackite**), and let the wind take over. We recommend pole flying in low to moderate winds only.

Kite Flying

Insert one end of slat through body and into beak. Tape the other end down inside the body. This slat reinforcement keeps the head from bending in the wind. Pinch Tyvek together on body and attach swivel through holes. Attach line to swivel. An exciting way to fly your **Jackite** is to attach it to the light-weight line of a fishing rod. Disengage the anti-reverse on the reel, enabling you to control the line. Because a **Jackite** is so wind sensitive, you can fly it on as little as ten feet of line. As it lifts to the sky, let out the line as it pulls upward. We like to fly our **Jackite** on about 100-200 feet of line, amazed as it flits across the sky. Emulating a bird in flight with a natural grace and beauty, your **Jackite** will actually flap its wings, soar to a new position, flaps its wings again and soar to another position. Lo and behold! Is it a goose or is it a **Jackite**? We fly our **Jackite** along a river to the delight of passing boaters.

Storage: Remove rod and hang by opening in the beak.

Display: You may desire to share the beautiful design of the **Jackite** with others as a decoration for your home or office. It's a real conversation piece. With three feet of line, tie one end of line to front ring and tie other end of line to back ring. Hang string at center point from ceiling. Enjoy