

# How to Use Your YULEYS®



**1 PLACE:** Place both YULEYS beside each other on the floor.



**2 STEP IN:** Step into them one at a time, toe first, pushing down on heel until firmly locked into place. Repeat for other foot. It's that easy!



**3 STEP OUT:** To remove YULEYS step on opposite heeltab and lift foot out. Repeat on other foot. Convenient hands-free removal.

## Just Your Size

Universal sizing guidelines make it easy to find the YULEYS® to fit your work boot or shoe. When trying to determine your YULEYS size, measure the sole of your footwear from heel to toe. When measured correctly, your YULEYS will fit snug.


Work Boot/Shoe Sole Length	YULEYS® Sizes
10 in. (25.5 cm) - 10 1/2 in. (26.7 cm)	A
10 1/2 in. (26.7 cm) - 11 in. (27.9 cm)	B
11 in. (27.9 cm) - 11 3/4 in. (29.8 cm)	C
11 3/4 in. (29.8 cm) - 12 5/16 in. (31.3 cm)	D
12 5/16 in. (31.3 cm) - 12 5/8 in. (32.0 cm)	E
12 5/8 in. (32.0 cm) - 12 15/16 in. (32.9 cm)	F
12 15/16 in. (32.9 cm) - 13 5/16 in. (33.8 cm)	G
13 5/16 in. (33.8 cm) - 13 3/4 in. (34.9 cm)	H
13 3/4 in. (34.9 cm) - 14 3/16 in. (36.0 cm)	I

\*If the length falls in a range between two YULEYS sizes, select the smaller size.

## Easy Cleaning and Care

YULEYS® are designed for today's busy companies and workers: simply rinse them off when you're done and let them air dry. YULEYS® are launderable and can be sterilized with bleach.

CE Pending



**YULEYS®**  
Clean Step System by HexArmor®

Call 1-877-366-5436 or visit [www.yuleys.com](http://www.yuleys.com)

**HexArmor®**

[www.hexarmor.com](http://www.hexarmor.com)