



P.O. Box 538 East Granby, CT 06026 PH:(860)844-0101 www.ShopWCS.com

Electronic CO2 Saver

**** No need to watch and wait until process is done to turn off your gas supply****
**** You can continue working while unit operates****

CO2 Saver allows you to program the “on” and “off” of gas flow used for Euthanasia.

- 1: Plug unit in with provided power supply
- 2: Turn unit power on (***alarm will be sounding***)
- 3: **—02** will appear. Press and Hold **A** button for **3** seconds.

You should see **—02** blinking
This shows the program number - **DO NOT CHANGE.**

- 4: Press **A** again one time (do not hold)
- 5: This will show **0000** with the last **0** blinking.
You must enter all time in total seconds;
Example: 10 minutes = 600 seconds
- 6: Press **B** until the digit you want to change blinks.

Pressing **B** twice would show **0000** blinking

- 7: Using the + & - buttons to enter in desired time for CO2 to be on.
- 8: To lock in your time press and hold **A** button for **3** seconds.
DONE—timer will automatically begin to count down.

To restart turn power OFF and ON again

**COUNT DOWN WILL IMMEDIATELY BEGIN WHEN
POWER IS FIRST TURNED ON.**

The time you just set will be saved when power is off.



Number of desired
minutes x 60 = total
second need to set.

5 seconds = 0005
10 seconds = 0010
5 minutes = 0300
10 minutes = 0600
15 minutes = 0900
20 minutes = 1200